sunlite INSTALLATION INSTRUCTIONS



WARNING: Read and understand these instructions before installing Fixture. This fixture is intended for installation in accordance with Network Constraint Control or Consoling Florational Control

National Electrical Code or Canadian Electrical Code (as applicable) and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, trun off all electricity before proceeding. Retain these instructions for maintenance reference.

49164-SU | LFX/SWP/30W/BRZ/50K | LED SLIM WALLPACK FIXTURE 49165-SU | LFX/SWP/50W/BRZ/50K | LED SLIM WALLPACK FIXTURE



Introduction

An internal power-factor-corrected switch-mode supply allows it to be used from any nominal 100V-277V, 60Hz AC supply without any variation in light output.

DIMMABLE* 0-10V Dimming


Suitable for use in the following locations:

- Ambient Temp: -40~+40°C
- Wet Locations

Installation


Refer to the following diagram when you install the fixture. Three installation methods, directly fix to the mounting surface, mounting pole or mounting stand.

Surface Mounting




Determine if fixture is equip with or without photocell. Utilize twist-on connectors to make electrical connections. Fasten the wires by the provided cable tie.

Mounting Pole



Mounting Stand



Direction of light can now be adjusted.

Mount the stand onto the mounting surface

box.

Sunshine Lighting Company 744 Clinton Street Brooklyn, NY 11231, USA **T.** 718.768.7000 **F.** 718.768.0970 www.sunlite.com