


# sunlite®

## INSTALLATION INSTRUCTIONS

LED STRING LIGHT | 80423-SU LED/SL/100'/50K



Please read and understand this entire manual before attempting to assemble, operate or install the product.

**WARNING:** Avoid fire or electric shock. This product should not be installed in heat and sealed environment and corrosive gases, and other places, so as not to affect the service life. Do not override any ignition of explosive materials on the surface, so as not to causes a fire. This luminaire must be installed, tested and maintained by professionals using special equipment. please check theproduct carefully after open package, if any products damaged, please keep the packaging and contact to the local dealer. Suitable for wet locations.

**CAUTION:** Turn off the power at fuse or circuit breaker box before installation and maintenance to avoid electric shock. This fixture requires a 120-Volt AC power source. This device is not intended for use with emergency exits., the cable can't be cut,not allowed to connect other electric device.This product is warranted to be free from defects in workmanship and material for up to 2 years. Based on reasonable household usage, when used in accordance with package and bulb directions, if this product does not last for the time period guaranteed (based on up to 3 hours average usage per day/7 days a week), Sunlite will send you a replacement product upon receipt of the returned, register receipt, and proof of purchase. Go to [www.sunlite.com](http://www.sunlite.com) and email us to find out how to return the product.

**This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful inference, and (2) this device must accept any inference received, including that may cause undesired operation.**  
*Retain these instructions for future maintenance reference.*



### SPECIFICATION

Output Power	Input Voltage	Light Effect	Lights	Wire Length	Lamp Base	Operating Temperature
100W ±10%	120 Vac	120 lm/W	10	100FT	Hook	5°F ~ 113°F

## Installation

Fig 1.





Fig 2.



- STEP 1.** Make sure the power is turned off at the source to the junction box.
- STEP 2.** Remove the cable tie during installation.
- STEP 3.** Tie the fixture on a fixed pipe through the hook with strong nylon cable or iron wire.
- STEP 4.** Restore power at the source.

**Sunshine Lighting Company**  
744 Clinton Street Brooklyn, NY 11231, USA  
T. 718.768.7000  
F. 718.768.0970  
[www.sunlite.com](http://www.sunlite.com)