

Important: Read all instructions prior to installation.

Linkable Integrated T8 Linear LED Light

User Manual

Safety and Notes

- Product should be installed in accordance with applicable national, state, and local electrical codes.
- To reduce the risk of electric shock, ensure that the main power source is switched off before performing any installation or wiring procedures.
- Product is for use in dry, indoor locations only.
- When installing multiple lights in a run, make sure to check for voltage drop. Minimum voltage must be maintained to avoid damaging lights. Maximum connected lights for a single run should not exceed the number listed in the table below.



Included Accessories

- Surface mounting bracket (x2)
- Mounting screws (x2)
- Plastic screw anchors (x2)
- Tube end cap (x1)
- 12 in. interconnect cable (x1)
- 60 in. power cord (x1)

Specifications

T8 Linear LED Light	
Operating Temperature	-4°–113° F (-20°–45° C)
Max Run	6

Installation Instructions

- 1.Remove supply power.
- 2.Drill pilot holes for mounting screws and install mounting clips approximately 1/4 of the total length from each end of fixture. For example, about 6 in. from each end of a 24 in. fixture. Repeat for all fixtures in the run.
- 3.Snap fixtures in place. Make connections between fixtures using supplied interconnect cable
- 4.Use tube end cap to cover unused power connector on the last fixture in the run.
- 5.Connect power cord to the first light in the run and plug into appropriate outlet.

