# sunlite®
CCT & POWER TUNER INSTRUCTIONS

SLIM FLAT PANEL FIXTURES

Change CCT Settings

The CCT changing switches allows for selecting the light temperature to match a wide range of applications.

The switches are conveniently placed on the fixture's back, allowing the user to choose between 3500K, 4000K, and 5000K before installation.

Set the two switches in the format shown to set the temperature required.


Change Power Settings

The wattage changing switch allows for selecting the required power needed.

The switch is conveniently placed on the side of the driver, allowing the user to choose between 30W, 40W, or 52W before installation.

Set the required wattage, simply by sliding the switch.