

INSTALLATION INSTRUCTIONS

CEILING FIXTURE

120VAC/60Hz

READ AND FOLLOW SAFETY INFORMATION

CAUTION - Turn off the main power at the circuit breaker before installing and servicing the fixture to prevent possible injury from electric shock.

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

INSTALLATION & ASSEMBLY

1. The **FIXTURE SCREWS (10)** is installed in the **OUTLET BOX (1)** and the **2/3** tooth section is exposed.
2. Connect the power supply wires to the fixture lead wires by connecting the **BLACK FIXTURE WIRE (7)** to the **BLACK SUPPLY WIRE (2)**, and the **WHITE FIXTURE WIRE (8)** to the **WHITE SUPPLY WIRE (6)** using **WIRE CONNECTOR (4)**. Connect the fixture **GROUND WIRE (5)** to the **SUPPLY GROUND WIRE (3)**.
3. Carefully tuck all wiring back into the **OUTLET BOX (1)**. Raise the **FIXTURE PAN (9)** to mounting surface allowing for **FIXTURE SCREWS (10)** to protrude through key slots. Rotate the **FIXTURE PAN (9)** clockwise until screws are in narrow part of key slots, and tighten securely.
4. Fix the **LAMPSHADE (11)** on the **FIXTURE PAN (9)** by rotating it.

Care Instructions:

WARNING: Always be certain that electric current is turned off before cleaning. Only a soft damp cloth should be used. Harsh cleaning products may damage the finish.

