

Note: For 81325-SU, sensor and dimming can't work together. One functionality should be turned off / not used.



sunlite

Junction Box Mounting

Step 1: Attach installation bracket with screws to junction box and connect ground wire (fig. A).

Step 2: Fix safety rope from installation bracket to fixture (fig. B).

Step 3: Connect black wire to live wire, white wire to neutral wire, and secure using quick connector (fig. C).

Step 4: Position fixture marking with mounted bracket and push up until it clicks into place (fig. D).

Note: To remove, pull down hard or use a flathead screwdriver to pry off.

Step 5: Select desired color temperature and motion sensor option located on the side of the fixture.

Installation Bracket Positioning Mark



Recessed Housing Mounting

Step 1: Attach housing clips to fixture bracket with screws, at desired location for size required (fig. E).

Step 2: Position fixture markings with fixture bracket and push down until it clicks into place. Connect white wire and black wire to the connector male terminal (fig. F).

Step 3: Twist screw base adapter to fixture socket as below (fig. G).

Step 4: Connect the quick connector. Push clips into recessed can to install fixture (fig. H & I).

